AFMSRX CALIBRATION

IF ERRATIC OPERATION OCCURS WHEN UNIT IS INITIALLY POWERED, ADJUST P5 UNTIL SYSTEM IS STABLE.

- 1. SET SPEED-ADJUST-POT (P8 ON FRONT PANEL) TO 0000; ADJUST P3 FOR 0.000 V AT TP3 (U4 OUTPUT).
- 2. ADJUST P2 TO CAUSE MOTOR TO COME TO DEAD STOP; ADJUST P7 FOR 0.000 V AT YELLOW OUTPUT JACK ON FRONT PANEL.
- 3. SET THE MOTOR SPEED TO 3600 RPM BY ADJUSTING THE SPEED-ADJUST-POT (P8) FOR ONE IMAGE OF THE MOTOR SHAFT WHEN A LINE-TRIGGERED STROBE IS FOCUSED ONTO THE SHAFT; ADJUST P6 FOR 3.60 V AT YELLOW OUTPUT JACK.
- 4. SET SPEED-ADJUST-POT (P8) TO 0200; ADJUST P2 FOR 0.200 V AT YELLOW OUTPUT JACK.
- 5. SET SPEED-ADJUST-POT (P8) TO 3600; ADJUST P4 FOR 1.44 V AT TP1.
- 6. ADJUST P5 FOR 3600 RPM OF MOTOR SHAFT AS INDICATED BY STROBE.
- 7. SET SPEED-ADJUST-POT (P8) TO 0100; ADJUST P2 FOR 100 RPM OF MOTOR SHAFT.
- 8. SET SPEED-ADJUST-POT (P8) TO 0000; APPLY 3.60 V TO THE GREEN INPUT JACK ON THE FRONT PANEL AND ADJUST P5 FOR ONE IMAGE OF THE MOTOR SHAFT AS INDICATED BY THE STROBE.
- 9. SET SPEED-ADJUST-POT (P8) TO 3600; ADJUST P4 FOR ONE IMAGE OF THE MOTOR SHAFT AS INDICATED BY THE STROBE.
- 10. REPEAT STEPS 7, 8, & 9.

